



YOUR SOURCE FOR EQUIPMENT RENTAL

HUNTSVILLE

7238 Governors W. Huntsville, AL 35806

GET IT RENTED GET IT DONE

NO TWO JOBS ARE THE SAME.

CONSTRUCTION

Why subcontract? Rent a Bobcat loader or excavator and boost profits by doing the work yourself. If you need to dig a trench, load materials, backfill or clean up, we can help!

LANDSCAPING

Bobcat's mini track loaders provide easy-to-use horsepower that fits just about anywhere. Replace hand labor and get work done quickly and efficiently in tight spaces.

CHORES AT HOME

No matter what job you need to finish on your property, Bobcat equipment can help—from moving dirt and land clearing, to installing fence and mowing.

Bobcat of Huntsville can help you find the right rental equipment to tackle your toughest jobs.

VISIT WITH US TODAY!

TODAY Huntsville

BOBCAT OF HUNTSVILLE

7238 Governors W, Huntsville, AL 35806



THE RIGHT EQUIPMENT. THE RIGHT ATTACHMENTS. RIGHT HERE. WWW.BOBCATOFHUNTSVILLE.COM

COMPACT EXCAVATORS

MODEL	WEIGHT	DIG DEPTH	REACH	
E32 (LA)	7,340	10'2" (11'2")	16'3"	
E35 (LA)	4,669	10'2" (11'2")	17'2"	
E45 (LA)	10,077	10'8" (11'8")	18'6"	
*E45 WITH 12'8" EXTENDABLE ARM AVAILABLE				
E50 (LA)	11,357	11'4" (12'8")	19'4"	
E55	12,004	12'9"	20'	
*E55 WITH 14'7" EXTENDABLE ARM AVAILABLE				
E85	18,960	15'5"	23'9"	

RATES INCLUDE ONE BUCKET PER POWER UNIT

EXCAVATOR ATTACHMENTS

15/30C AUGER BITS (6"-18")
15/30C AUGER BITS (24"-30")
15/30C AUGER BITS (36")
HB880 /HB980 CONCRETE BREAKER
HYDRAULIC CLAMP
MULCHING HEAD

MINI TRACK LOADERS

MODEL	ROC	HP
MT85	850	25
MT100	1,000	24.5

RATES INCLUDE ONE BUCKET PER POWER UNIT

MINI TRACK LOADER ATTACHMENTS

MODEL
PALLET FORKS
GRAPPLE
40" TILLER
AUGER (6"-24" BITS)
LT113 TRENCHER
48" SOIL CONDITIONER

SKID-STEER LOADERS

MODEL	ROC	HP
S650	2,690	74
S76	2,900	74
S770	3,350	92

RATES INCLUDE ONE BUCKET PER POWER UNIT

COMPACT TRACK LOADERS

MODEL	ROC	HP
T450	1,400	55
T550	2,027	68
T590 / T595	2,200	66/70
T62	2,150	68
T64	2,300	68
T66	2,450	74
T76	2,900	74
T740	3,200	74
T750	3,325	85
T770	3,475	92
T870	3,650	100

LOADER ATTACHMENTS

MODEL

HB880/HB980 CONCRETE BREAKER

PALLET FORKS

SOD LAYER

SWEEPER (60", 72")

LANDSCAPE RAKE

15/30C AUGER (6"-36" BITS)

72" SOIL CONDITIONER

ROTARY TILLER

ROOT GRAPPLE (68", 74")

INDUSTRIAL GRAPPLE (68", 74")

60" FORESTRY CUTTER, 2 SPEED (HI FLOW)

72" BRUSHCAT (STD FLOW)

SG60 STUMP GRINDER

LT313 TRENCHER

24" PLANER (HI FLOW, MILLING ATTACHMENT)

60" DIAMOND ROTARY MOWER

72" DIAMOND ROTARY MOWER

60" DIAMOND FORESTRY CUTTER, ROTARY (HI FLOW)

60" SKID-STEER DRUM MULCHER, BOBCAT (HI FLOW)

72" DRUM MULCHER, DIAMOND MOWERS (HI FLOW)



TERMS & CONDITIONS

(Visit www.bobcatofhuntsville.com/rental for additional information)
Rental rates are based upon a maximum of 8 hours operation per 24 hour day, 40 hours per 7 day week, and 160 hours per 28 day 4-week period. After third week,the fourth week is free. Overtime hours will be prorated. All equipment is subject to availability. A cleaning fee will apply for any excessive concrete, asphalt, animal excrement. All rates do not include taxes, Rental Protection Plan Fee, delivery and/or pickup.

PROOF OF INSURANCE IS REQUIRED FOR FULL VALUE OF RENTED EQUIPMENT. If liability insurance is not provided, a Rental Protection Plan Fee of 15% will be applied to the total equipment rental charge.

No hourly rates, one day minimum. Rental charges are from time out to time back. Customers will be charged per gallon on machines not returned full of fuel. All prices FOB our facilities. Delivery/pickup available for additional charge, ask for rates. Any and all abuse or damage to rental equipment will be invoiced to customer accordingly. Extra fuel not provided during rental period.

Bobcat of Huntsville Responsibility:

- To furnish the machine in working condition FOB lessor's vard.
- To account for any major repair or breakdown due to a defect in material or workmanship.
- Rental rates are subject to change see dealer for details.

Customer's Responsibility:

- To properly maintain the machine (greasing, oil, filter changes, and fuel supply) and return it as it was received, excepting normal wear, reporting to the dealership any mechanical problems. Any necessary tire repairs are the customer's responsibility.
- To account for damages due to abuse or neglect to the equipment and accept full liability for all actions resulting from machine use.
- To properly secure equipment during rental period.

CALL FOR RATES & AVAILABILITY.